



OPTEK HALL EFFECT SENSOR OMH3075

**A. Sanders¹, H.S. Kim², A. Phan²
and C. Poivey²**

- 1. NASA/GSFC, Code 561.4 Greenbelt, MD
20771**
- 2. NASA/MEI, Greenbelt, MD 20771**



Outline



Sample Analysis at Mars (SAM)


- **Introduction**
- **Background**
- **Requirements**
- **Test Configuration**
- **Test Techniques**
- **Test Results**
- **Summary**
- **Acknowledgements**



Hall Effect



Sample Analysis at Mars (SAM)



Hall Effect Diagram

- 1. Electrons
- 2. Hall element, or Hall sensor
- 3. Magnets
- 4. Magnetic field
- 5. Power source
- In "A", the Hall element takes on a negative charge at the top edge and positive at the lower edge.
- In "B" and "C", either the electric current or the magnetic field is reversed, causing the polarization to reverse.
- In "D", reversing both current and magnetic field causes the Hall element to again assume a negative charge at the upper edge.




Optek Hall Effect Sensor



Sample Analysis at Mars (SAM)

- Contains a monolithic integrated circuit which incorporates a Hall element, a linear amplifier, a threshold amplifier, and Schmitt trigger on a single Hallogics® silicon chip.
- Included on-chip is a band gap voltage regulator to allow operation with a range of 4.5 to 24 volt supply voltages.
- Output amplitude is constant at switching frequencies from DC to over 200 kHz.
- The Bi-Polar device turns on (logic level “0”) in the presence of a magnetic south pole and turns off (logic level “1”) when subjected to a magnetic north pole.



Internal Optek Hall Effect Sensor



The Mission



Sample Analysis at Mars (SAM)


- The Mars Science Laboratory (MSL) project plans to launch a rover to a single location on Mars in the October - November 2009 launch opportunity as a part of the NASA OSS Mars Exploration Program (MEP).
 - MSL will conduct a Mars habitability investigation, with habitability defined as the “capacity of the environment to sustain life”, i.e., the potential of a given environment to support life at some time, past or present.
- The MSL Rover will be launched from the NASA Kennedy Space Center Eastern Test Range, on an intermediate-class (e.g., Delta IV or Atlas V) launch vehicle
 - The cruise phase lasts approximately 10 to 14 months and begins when the spacecraft separates from the launch vehicle and ends prior to Mars entry, descent, and landing (EDL). The Rover will remain enclosed inside an aeroshell during the entire cruise.
 - The landing date ranges from May 2010 to not later than December 2010.
- The EDL phase begins when the vehicle reaches Mars altitude of approximately 125 km, and ends with a soft touchdown of the Rover on the Martian surface followed by the flyaway of the “sky-crane” descent stage.
- After landing, the primary landed mission operations will commence and last for approximately one Martian year, 670 sols (687 Earth days).



MSL Rover Configuration



Sample Analysis at Mars (SAM)







SAM Instrument



Sample Analysis at Mars (SAM)




SAM Pre-CDR Detector Electronics Peer Review – November 17, 2006





Key Subsystems


Sample Analysis at Mars (SAM)




[SMS](#) – Honeybee Robotics
[CSPL](#) – GSFC
[QMS](#) – GSFC
[GC](#) – U.Paris/CNRS
[TLS](#) – JPL
[Electronics](#) – GSFC,
J.Maurer (consultant), Battel
Engineering
SEE Symposium April 10-12, 2007



Sample Manipulation System (SMS)



Sample Analysis at Mars (SAM)



The SMS:

- Holds 88 sample cups
- Moves cups to the sample inlet
- Moves filled sample cups to the CSPL pyrolysis oven

Honeybee Robotics



Test Requirements



Sample Analysis at Mars (SAM)


- **Determine the Single Event Latchup (SEL) and Single Event Transient (SET) susceptibility of the Optek Hall Effect Sensor, OMH3075, for transient interruptions in the output signal and for destructive events induced by exposing it to a heavy ion beam at the Lawrence Berkeley National Laboratory (LBNL). Utilizing the Berkeley Accelerator Space Effects Facility (BASEF), this test was performed for the potential use in electronic circuitry for the Sample Analysis at Mars (SAM) Instrument as a part of the Mars Science Laboratory (MSL) Project.**
- **The design engineers on the project had pre-selected this device to control the motors of the Sample Manipulation System (SMS) of the SAM Instrument. This device needed to meet the SEL requirement of $>80 \text{ MeV-cm}^2/\text{mg}$ for the Mars Mission.**



Test Board



Sample Analysis at Mars (SAM)



Hall Effect Sensor


Magnetic Coil

The Optek Hall Effect Sensor OMH3075 Test Board



Test Configuration

Sample Analysis at Mars (SAM)






Test Board Alignment



Sample Analysis at Mars (SAM)



The Optek Hall Effect Sensor OMH3075 mounted for beam at LBNL



Ion Beam Characteristics



Sample Analysis at Mars (SAM)

Ion	LET (MeV·cm ² /mg)	Angle (degrees)
Xe	58.7	0
Xe	67.8	30
Xe	83.0	45

- **Facility:** Lawrence Berkeley National Laboratory, 10MeV/amu tune
- **Flux:** 1.47×10^3 to 1.26×10^5 particles/cm²/s.
- **Fluence:** 1×10^7 p/cm² or until destructive

OMH3075 Heavy Ion Testing at Room Temperature at LBNL



Test Techniques

Sample Analysis at Mars (SAM)


Vsensor	Sensor	Magnet	Vmagnet
5V	On	Inserted	+3V
5V	Off	Inserted	-3V
5V	On	Removed	0V
5V	Off	Removed	0V

South Pole Present

North Pole Present

No Magnet Present

No Magnet Present



Test Methods of the Optek Hall Effect Sensor using a magnet



On and Inserted Mode



Sample Analysis at Mars (SAM)

Vsensor	Sensor	Magnet	Vmagnet
5V	On	Inserted	+3V
5V	Off	Inserted	-3V
5V	On	Removed	0V
5V	Off	Removed	0V


South Pole Present: logic level "0"

Sensor On and Magnet Inserted

Sensor Off →

FWHM Transient of 14us at 1.72V →

Sensor On →





Off and Inserted Mode




Sample Analysis at Mars (SAM)

North Pole Present: logic level "1"

Sensor Off and Magnet Inserted

Vsensor	Sensor	Magnet	Vmagnet
5V	On	Inserted	+3V
5V	Off	Inserted	-3V
5V	On	Removed	0V
5V	Off	Removed	0V



← Sensor Off

← FWHM Transient of 6us at 1.98V

← Sensor On



Magnet Removed Modes




Sample Analysis at Mars (SAM)

Vsensor	Sensor	Magnet	Vmagnet
5V	On	Inserted	+3V
5V	Off	Inserted	-3V
5V	On	Removed	0V
5V	Off	Removed	0V


Transient of at least 80us for sensor on or off conditions

No Magnet Present

No Magnet Present



Switch Off and Magnet Removed



Switch On and Magnet Removed



Conclusion



Sample Analysis at Mars (SAM)

- **On and inserted mode:**
 - Full Width Half Max Transient of 14us
 - Magnetic pulls sensor back to on condition after transient event
- **Off and inserted mode:**
 - FWHM Transient of 6us
 - Magnetic pulls sensor back to off condition after transient event
- **On/Off and removed mode:**
 - Transient of at least 80us captured
 - Sensor remains in opposite condition after transient event



Results Summary

Sample Analysis at Mars (SAM)


- **Three Optek Hall Effect Sensor OMH3075 devices did not experience SEL up to an LET of 83 MeV/(mg/cm²).**
- **The devices were exposed from a fluence of 9.74×10^3 to 1.00×10^7 particles/cm² of the Xenon ion beam per run.**
- **Transients were observed for all runs that can be handled through mitigation with magnet present.**
- **Magnetic presence is needed to return device to current condition after a transient event has occurred.**



Acknowledgements

Sample Analysis at Mars (SAM)

**Dave Sheppard
Bruce Meinhold
Lou Fetter**



Sample Analysis at Mars (SAM) Instrument